

DURASCAPETM

DurascapeTM is a 9mm-thick base sheet. Designed for covering large areas, its 5mm wide shiplap joint gives the sheet a subtle vertical shadow line. To create an appealingly 'rendered' look, finish DurascapeTM onsite with a roll-on textured paint.

APPLICATION

Exterior cladding.

AUSTRALIAN STANDARDS

Manufactured to conform to the requirements of AS2908.2 Cellulose-Cement Products and are classified as Type A Category 2 for external use.

Tested in accordance to AS1530.3.

INSTALLATION

DurascapeTM panels can be installed vertically to both timber and lightweight steel frames.

DurascapeTM panels should be installed vertically with all sheet edges fully supported. The centre joints must coincide with the centre lines of the framing member and all sheets should be installed in one direction.

At every vertical joint, fix a continuous strip of EPDM Foam Gasket to the vapour permeable sarking along the stud. This assists to prevent the ingress of moisture at the sheet joints. Position the underlap sheet on every stud 3mm past the centre of the stud to ensure the fasteners fixed at the edge of the sheet have adequate distance into the stud.

To fix the first sheet, set in place ensuring the required edge distances are maintained.

Apply of continuous 4mm bead of sealant to the edge of the shiplap joint.

Once both sheets are fixed, check the joint for gaps and fill with additional sealant if required.

Refer to the DurascapeTM brochure for complete installation instructions –
www.innovafibreceement.com.au